

Operation instructions Controller for air handling units CU24V2-L



WWW.VENTIAIR.COM





WARNING: Please read this manual carefully before connecting the panel



Contact:

VentiAir s.r.o. Adolfovice 512 790 01 Bělá pod Pradědem CZ – Czech Republic IČ: 06935320 DIČ: CZ06935320 email: obchod@ventiair.com; technical@ventiair.com tel.: +420 602 500 287

The device is manufactured in accordance with the European standard EN1886, EN13053

This documentation must always be handed over to the customer! In case of non-compliance with the conditions stated in this documentation, VentiAir s.r.o. reserves the right to refuse the warranty.

Regular Production Surveillanc Safety TÜVRh www.tuv.com





Version 01/2025





WARNING!!

When connecting the panel to the controller, take care not to change the GO earth voltage cable $\frac{3}{2}$ with G phase cable in one of the devices.

Reversing these cables in one of the devices will lead to a short-circuit between G and G0 through the RS485 output and to the damage of this output.

24 V AC power supply should be connected as below:

- G0 earth voltage cable should be connected to terminal No. 1
- G phase cable should be connected to terminal No. 2











VentiAir s.r.o. Adolfovice 512 - Bělá pod Pradědem Czech Republic, IČ: 06935320



1 CONTENTS

2	WIRING DIAGRAM OF CU24V2 – Global wiring						
3	Terr	ninal	S	7			
4	Pan	Panel connection					
5	OPF	OPERATION					
5		Daci	a functions	o			
	5.1	Basi	c functions	δ			
	5.2	Pow	ver on and scanning the network	9			
	5.3	Key	s description:	9			
	5.4	Logi	n	10			
	5.5	Alar	m list	11			
	56	Hon	ne nage and setmoint editing	13			
	5.0						
	5.7	Swit	Iching home screen views	14			
	5.8	Abb	reviation description	14			
	5.9	Арр	lication setting	16			
	5.10	Me	enu overview and parameters setting	17			
	5.10).1	Menu #1 Zone 1 – All days				
	5.10).2	/ Menu #2 Zone 2 – All days				
	5.10).3	Menu #3 Zone 3 – All days				
	5.10).4	Menu #4 Zone 4 – All days				
	5.10).5	Menu #5 Zone 5 – All days				
	5.10).6	Menu #6 MAN program – All days				
	5.10).7	Menu #7 Utility programs				
	5.10).8	Menu #8 Application List	19			
	5.10).9	Menu #9 AHU set: heat/cool	19			
	5.10).10	Menu #10 AHU set: recovery	20			
	5.10).11	Menu #11 AHU set: temp control	21			
	5.10).12	Menu #12 AHU set: fan	21			
	5.10).13	Menu #13 AHU set: CO ₂ , pressure	21			
	5.10).14	Menu #14 AHU set: others	21			
	5.10).15	Menu #15 Supply temperature set	22			
	5.10).16	Menu #16 Cooling unit	22			
	5.10).17	Menu #17 DX unit	22			
	5.10).18	Menu #18 Exchanger	233			
	5.10).18	Menu #19 Recirc. damper.	233			
	5.10).19	Menu #20 Bypass and GHE	23			
	5.10).20	Menu #21 Heating set	24			
	5.10).21	Menu #22 Ventilating	24			
	5.10).22	Menu #23 PID set: Heating	25			
	5.10).23	Menu #24 PID set: Cooling	25			









4

PZH ODUKT Z ATESTEM OLECNOST. VentiAir s.r.o. Adolfovice 512 - Bělá pod Pradědem Czech Republic, IČ: 06935320

PROD

💮 ase<mark>ko</mark>l



STÁTNÍ ZDRAVOTNÍ ÚSTAV

SZÚ

	5.10).24	Menu #25 Heat–Cool hyst	25
	5.10).25	Menu #26 PID set: CO ₂	25
	5.10).26	Menu #27 PID set: pressure	26
	5.10).27	Menu #28 PID set: humidifying	26
	5.10).28	Menu #29 Measure ranges	26
	5.10	1.29	Menu #30 Units and flow	26
	5.10	0.30	Menu #31 Fan setting	27
	5.10).31	Menu #32 Gear setting	27
	5.10	1.32	Menu #33 Clock	27
	5.10	1.33	Menu #34 Communication	28
	5.10	1.34	Menu #35 Simulation	28
	5.10	1.35	Menu #36 Password setting	28
	5.10	1.36	Menu #37 Language select	29
	5.10	1.37	Menu #38 Information	29
	5.10	1.38	Menu #39 Login	29
6	Ethe	ernet	·	.30
	6.1	sam	nple interface pages:	.30
	6.2	Con	inection	.30
	6.3	LED	description	.30
	6.4	Con	verter connection	.31
	6.5	Con	verter settings	.31
7	CU2	4V2	CONTROLLER – MODBUS REGISTER LIST	.32
	7.1	Reg	ister list with address (Function 03, 06)	.32
	7.2	Орє	erating state register description	.34
	7.3	Alar	rm register description R1H, R1L	.35
	7.4	Inpι	ut registers: function 04	.36
	7.5	Coil	ls (Digital Outputs): function 01	.36
	7.6	Disc	cret inputs (Digital inputs): function 02	.36

SK*





WIRING DIAGRAM OF CU24V2 – GLOBAL WIRING











7

TERMINALS 3

L-N	230VAC power line supply
PE	Ground
Тр-Тр	Primary windings of the transformer:
	The L-N powerline is internally connected to Tp-Tp to supply the primary windings of the transformer
G0-G	24VAC Power supply for the controller: G0 is the (-) terminal and G is the (+) terminal. The 24VAC secondary windings of the transformer should be connected to G0-G
Μ	Signal ground for analog inputs B1-B5, X1-X3, digital inputs E1-E8, 0-10V outputs Y1-Y7, PWM outputs P1, P2
B1-B5	Resistive PT1000 inputs
X1-X3	Analog inputs 0-10VDC
E1-E8	Digital inputs, potential-free contacts
	Do not apply voltage to the E1 E8 digital inputs.
Q1, Q2	24VAC output for direct supplying of damper actuators, 4A max load
Q4-Q8	Relay outputs - closing contacts, 4A max load
Y1-Y7	Analog outputs 0-10VDC
P1, P2	Modulated outputs 21V DC: electric heat current valves driving
Connect the dev	vice to be controlled (e.g. a semiconductor relay) to P1(+) and M(-) or P2(+) and M(-)

- A1, B1 Serial interface RS485
- A2, B2 Serial interface RS485









💬 asekol

ZE STARÉHO NOVÉ!

SZÚ



4 PANEL CONNECTION

No.	Туре	Description	
1	Power supply (-)	G0: Supply earth voltage	
2	Power supply (+)	G: +24V AC	
3	Unused	-	
4	M	Ground	
5	A	Social interface DC40E	
6	В	Serial Interface RS485	

5 OPERATION

The **CU24V2** controller is a configurable controller for HVAC AHUs. The rich configuration options of the controller allows to create applications for AHU in almost all configurations. The controller comes complete with a 4.3" wall-mounted color touch panel **RMC30**, which allows you to create applications, parameterize the controller and manage the unit. The panel has a built-in very innovative and intelligent interface that allows the user to easily and clearly program the controller and navigate in the menu system. It has a unique solution consisting of a built-in guide, which during navigation in the menu, prompts the user how to use the buttons and explains the parameter designations, so there is no need to consult the instructions. When creating an application, the user only selects which functions he wants to use, while the controller sets the input/output for the task depending on the selected other functions, then the selection is displayed on the panel in real time. The I/O list of the built application along with the description and visualization is made available and can be consulted when connecting devices to the controller.

5.1 BASIC FUNCTIONS

- Temperature control
 - Cascade temperature control with min/max limitation. or airflow adjustment
 - Water and electric heater control
 - Water cooler and chiller control
 - Heat pump control
 - Pre-heating function
 - Active water heater frost protection
 - Protection of electric heaters against overheating
 - Preliminary heater
 - Cascade connection of two heaters: I and II section
- Fan control
 - Supply and exhaust fan control









8

VentiAir s.r.o. Adolfovice 512 - Bělá pod Pradědem Czech Republic, IČ: 06935320



- Frequency converter control
- Engine alarm -
- Fan pressure switch
- Control of heat recovery system
 - Rotary, cross and glycol exchanger control
 - _ Mixing chamber control
 - Exchanger freezing protection
- CO₂ regulation
- Supply and exhaust pressure regulation
- Humidity control
- Real time clock with weekly work schedule
- Alarms
 - Signalling and alarm management -
 - _ Alarm history overview
- BMS
 - Possibility to connect to the BMS system via the RS485 serial link -
 - **MODBUS** communication protocol

5.2 POWER ON AND SCANNING THE NETWORK

At power on RMC30 panel will scan the network to find device. The address of the device is displayed in the top right corner and is preceded by the character "@". After a device is detected data will be loaded from it before the panel can start operating. During data loading an animation appears on the top-right side of the display. After power on wait until full data load full display of information before using the keys to navigate.

5.3 **KEYS DESCRIPTION:**



Entering the **Menu** review or entering the parameter editing mode in the Menu.



Scrolling the menu backward or change parameter value during setting.



Scrolling the menu forward or changing the parameter value during setting.



Switching main screen views or moving to the next parameter during setting.



The AHU is working. Pressing switches off the AHU. The AHU is off. Pressing turns on the AHU.



Selection of program AUTO, MAN, PRO1, PRO2. Each press switches to the next value on the list.

ZE STARÉHO NOVÉ!











VentiAir s.r.o. Adolfovice 512 - Bělá pod Pradědem Czech Republic, IČ: 06935320





9



5.4 LOGIN

The CU24V2 controller has 3 access level:

- Level 0: level at power on without login
- Level 1: User, password at factory set: 0
- Level 2: Admin1, password at factory set: 0
- Level 3: Admin2, password at factory set: 11

Level 3 is the highest and gives access to the editing of any parameter.

All parameters can be viewed without need to log in with any password. But editing the parameters values are done according to the login level for the parameter. Parameters that are not allowed to be changed without password have * or ** displayed. The number of * is the log in level needed for the parameter to be edited. A parameter without symbol * or ** can be changed.

To login:

3.

- 1. Click SET and hold (about 1-2 sec) until the first Menu page Menu #1 Zone 1 All appears.
- 2. Go to Menu #38 LOGIN (last page in the menu system) by pressing



- Click on ser and hold until the value of LOGIN changes from white to green. Editing mode is indicated by a red circle ser .
- 4. Enter the password with the button

5. After entering the password click and hold *set* until the color of the parameter value goes out (green to white color). The red circle in the button will also turn off and go back to

After validating the password the **LOGIN** level will be displayed and be > 0. If the password is not valid the displayed LOGIN level will be 0.

Once the password is validated it will be valid you can change parameters values according to you login level. After leaving the menu system and back to main view the password will still be valid for one minute, so when you come back to menu system again you don't have to login. But if you stay out of the menu system for more than one minute the password validation will be cancelled and you will have to login again to edit parameters.

Until you don't leave the menu system the password validation is active.









10

VentiAir s.r.o. Adolfovice 512 - Bělá pod Pradědem Czech Republic, IČ: 06935320



5.5 ALARM LIST

To view the alarm list switch the display views using the 🕞 button, or touch the Alarm light area when an alarm is activated.

Clearing alarm with the "clear" button can be done only after logged in with password.

Alarm nr	Alarm name	Description
1	Heater freeze	Operation:
		Water heater frost alarm occurs when the digital input E2 is
		opened.
		The alarm stops the AHU and open the heater valve at 100% to
		protect the heater.
		Alarm clearing:
		To clear the alarm the input E2 should be closed, then alarm can be
		cleared by the "clear" button if the parameter FOVER = MAN or
		automatically cleared if FOVER = AUTO. See FOVER in Menu #20.
2	Engine failure	Operation:
		Engine failure alarm occurs when input E3 is opened .
		The alarm stops the AHU.
		Alarm clearing:
		To clear alarm input E3 should be closed, then clearing is done by
		click on START button to start the AHU or by the "clear" button.
3	Fan pressure-1	Operation:
		Supply/Extract fan pressure guard alarm occurs when input E4 is
		opened for a time longer than the time set by the parameter PREST
		(Menu #30).
		The alarm stops the AHU.
		Alarm clearing:
		To clear alarm input E4 should be closed, then clearing is done by
		click on START button to start the AHU or by the "clear" button.
4	Fan pressure-2	Operation:
		Extract fan pressure guard alarm.
		There is no separate input for extract fan pressure guard, and bot
		supply and extract fan pressure guards should be connected to
_		input E4.
5	Fire alarm	Operation:
		Fire alarm occurs when input E8 is opened .
		The alarm stops the AHU.
		Alarm clearing:
		To clear alarm input E8 should be closed, then clearing is done by
		the clear button. After clearing the AHU can be started by START
6	llitomporture	Ducton.
σ	ni temperature	Uperation:
		The alarm quitch of all boaters but does not stop the AUU
		Alarm cloaring:
		Alarm clears automatically after input 51 is closed
		Alarm clears automatically after input ET IS closed.









11

PZH VentiAir s.r.o. Adolfovice 512 - Bělá pod Pradědem Czech Republic, IČ: 06935320

TEM

20

asek



7	Exchanger	Operation:
	freeze	Exchanger freeze alarms occurs when the temperature sensed at
		the exchanger outlet falls below the value set by parameter EPRO
		(Menu #10).
		The alarm opens fully the bypass damper or stops the rotary
		exchanger, but does not stop the AHU.
		Alarm clearing:
		Alarm clears automatically after the temperature has raised above
		the set alarm value EPRO by 1 C.
8	Chiller alarm	Operation:
		Chiller alarm occurs when input E6 is closed .
		The alarm switch off the cooling unit but does not stop the AHU.
		Alarm clearing:
		- Manually clearing using the "clear" button with input E6 opened
		- Automatically cleared when input E6 is opened and after 5 min
		have elapsed from the time the alarm occurred.
		- Stop the AHU then start again. The alarm clears automatically at
		start.
9	Pump failure	Not available
10	Filters alarm	Operation:
		Filters guards alarm occurs when input E5 is closed .
		Alarm clearing:
		Alarm clears automatically after input E5 is opened .
		There is one common input dedicated to filters guards. All filters
		guards should be connected in parallel to the input E5.
19	Low water	Not available
	temp.	
20	Sensor break	Operation:
		Sensor break alarm occurs when the main temperature sensor is
		not connected at input B1 or when there is a short circuit.
		Alarm clearing:
		Automatically cleared after sensor is connected.
22	Low pressure-1	Operation:
		Switch off the compressor 1
23	High pressue-1	Operation:
		Switch off the compressor 1
24	Water leak	Operation:
		Switch off the evaporator if parameter WLEAK = Yes (Menu #17)
25	Low pressure-2	Operation:
		Switch off the compressor 2
26	High pressue-2	Operation:
		Switch off the compressor 2











VentiAir s.r.o. Adolfovice 512 - Bělá pod Pradědem Czech Republic, IČ: 06935320

💮 ase<mark>ko</mark>l

ZE STARÉHO NOVÉ!

STÁT ZDRA ÚSTAV

SZÚ



5.6 HOME PAGE AND SETPOINT EDITING

The home page contains all the most important information of the HVAC unit and enables direct editing of setpoints such as temperature, fan speed, work program and switching on/off of the unit, without having to scroll the screens to search for information.



Note: The temperature changes every 0.5 C. For a more accurate temperature editing, this should be done within the time schedule.













5.7 SWITCHING HOME SCREEN VIEWS

The RMC30 panel enables displaying all information from the HVAC unit. This information is grouped into several views that can be switch with the key in the order shown below.



Alarms display



5.8 ABBREVIATION DESCRIPTION

Abbreviation description for input

Shortcut	Description
Main	Main sensor
Supply	Supply sensor
Outdoor	Outdoor sensor















VentiAir s.r.o. Adolfovice 512 - Bělá pod Pradědem Czech Republic, IČ: 06935320



Exch	Exchanger sensor			
GHE	GHE temperature sensor			
Pre-heat	Preliminary heating temperature sensor			
CO2	CO ₂ transducer			
Hum	Humidity transducer			
Pres-1	Pressure transducer 1			
Pres-2	Pressure transducer 2			
Frost	Frost thermostat			
Pres-S	Supply fan pressure guard			
Pres-E	Extract fan pressure guard			
Engine al	Engine alarm			
Aprot	Cooling unit alarm			
Fire	Fire alarm			
Hi temp	Hi temperature alarm			
Pump al	Pomp alarm			
Filter	Filter alarm			
Start	Start/stop input			
Cust-1	Custom function 1 input			
Cust-2	Custom function 2 input			

Abbreviation description for output

Shortcut	Description			
Heat-1	Main heater (first heating step)			
Heat-sec	Secondary heating (second heating step)			
Heat-1 E	Electric heater (first heating step)			
El. heat	Electric heater supply			
Cooling	Cooling control			
Agr-1	Cooling unit – 1 step			
Agr-2	Cooling unit – 2 step			
Exch	Exchanger control			
Damper	On/off damper			
Recirc	Recirculation control (mixing chamber)			
Bypass	Bypass control			
GHE	GHE control			
Pump-H	Water heater pump			
Pump-C	Water cooling pump			
Pump-ex	Exchanger pump			
Heat P	Heating pump			
CO2	CO ₂ control			
Pres-1	Pressure control-1			
Pres-2	Pressure control-2			
Sup fan	Supply fan control			
Ext fan	Extract fan control			

















VentiAir s.r.o. Adolfovice 512 - Bělá pod Pradědem Czech Republic, IČ: 06935320

15



5.9 **APPLICATION SETTING**

The CU24V2 controller has built-in some predefined applications that can be selected from a list by setting the parameter APP. To manually define your own application set the parameter APP = USER. When a predefined application is selected (APP is other than USER) the items in the menu for manual defining an application will be disabled.

Nr	Heating	Cooling	Preheat	Sec heat	Exchanger	Recirculation	Heat	CO2			
					(bypass)		pump	control			
	Heat recovery units with on/off bypass control										
1-rec	P2	-	-	-	Q2	-	-	-			
2-rec	P2	-	P1	-	Q2	-	-	-			
			A	HU with wat	ter heater						
3-w	Y4	-	-	-	Y6, Q2	-	-	I			
4-wx	Y4	Q6	-	-	Y6, Q2						
5-wxr	Y4	Q6	-	-	Y6, Q2	Y7	-	I			
			AF	IU with elec	tric heater						
6-е	P2	-	-	-	Y6, Q2	-	-	I			
7-ex	P2	Q6	-	-	Y6, Q2	-	-	I			
8-exr	P2	Q6	-	-	Y6, Q2	Y7	-	-			
	AHU with heat pump										
9-hp	Y4	Y4, Q7	-	-	Y6, Q2	-	Q6	-			
10-hp	Y4	Y4, Q7	-	P2	Y6, Q2	-	Q6	-			
	AHU with CO ₂ control										
11-со	Y4	Q6	-	-	Y6, Q2	-	-	Y1, Y2			

PZH

TEM

Predefined application list:

The setting below is common to all the **predefined applications**:

Q1

- Supply fan inverter control: Υ1

- Supply fan inverter start: Q4

- Extract fan inverter control: Y2
- Extract fan inverter start: Q5
- On/Off dampers:
- Water heater pump: U1-U2









16



5.10 MENU OVERVIEW AND PARAMETERS SETTING

1. Click smand hold until the first page Menu #1 of the Menu appears (about 1 sec).

Menu #1 Zone 1-All days						
Rolling pages:		START : 00.00	SET			
Setting:		STOP : 00.00				
Tape and hold on SET		SV1 : 22.0 C				
Select parameter		CO2 : 0 %				
Setting the value:		SV3 : 0 Pa				
		SV4 : 0 Pa				
To finish: SET		SPEED: 2				

2. There are two ways to search parameters:



until you find the parameter.

- b. Faster method:
 - Click on Menu #1 to open the page with the menu contents as below

Menu list	@1
1: Zone 1	
2: Zone 2	SET
3: Zone 3	
4: Zone 4	
5: Zone 5	
6: MAN program	
7: Utility programs	
8: Application list	

Scroll with the buttons to search the relevant chapter
Click on a chapter to directly open its page with the parameter list

- 3. To enable editing parameters, click on set and hold until the color of the first parameter from the list changes. Editing mode is indicated by a red circle set.
- 4. Set the desired parameter value with the buttons
- 5. To switch to the next parameter click
- 6. To finish editing click and hold structure until the colour of the parameter value goes out. The red circle in the button will also turn off and go back to structure.
- 7. To exit the Menu section and return to the home page, click .

Note: To switch days of the week in the schedule (Menu #1 to Menu #6) press in the menu title "All days".









5.10.1 Menu #1 Zone 1 – All days

Name	Default setting	Range	Description
START	00.00	00.00 ÷ 23.59	Time zone start time
		G:M	
STOP	00.00	00.00 ÷ 23.59	Time zone end time
		G:M	
SV1	22.0	-24.0 ÷ 69.0 °C	Set temperature
CO2/SV2	0	0 ÷ 100 %	Set value of CO ₂ or humidity
SV3	0	0 ÷ 1000 Pa,%	Set value of for pressure, CO ₂ or humidity
SV4	0	0 ÷ 1000 Pa,%	Set value of for pressure, CO ₂ or humidity
SPEED	2	1÷4	Fan speed

5.10.2 Menu #2 Zone 2 – All days

As above

- 5.10.3 Menu #3 Zone 3 All days
- 5.10.4 Menu #4 Zone 4 All days
- 5.10.5 Menu #5 Zone 5 All days
- 5.10.6 Menu #6 MAN program All days

Name	Default setting	Range	Description
TIME	00.00	00.00 ÷ 23.59	Program running time
		G:M	
SV1	22.0	-24.0 ÷ 69.0 °C	Set temperature
CO2	0	0 ÷ 100 %	Set value of CO ₂ or humidity
SV3	0	0 ÷ 1000 Pa,%	Set value of for pressure, CO ₂ or humidity
SV4	0	0 ÷ 1000 Pa,%	Set value of for pressure, CO ₂ or humidity
SPEED	2	1÷4	Fan speed

5.10.7 Menu #7 Utility programs

Name	Default setting	Range	Description
PRO1	OFF	OFF, S4-E4,S1-E4, S0-E4,S1-E1, S4-E1, S4-E0	Work program for fans. The program is controlled by the defined digital input following the activation of the parameter PR1IN in Menu #14. It performs according to the set value if PROT is selected as program and the digital input is activated. OFF: turning off the program S-supply; E-extract The number after the letter indicates the fan speed













VentiAir s.r.o. Adolfovice 512 - Bělá pod Pradědem Czech Republic, IČ: 06935320



PRO2	OFF	OFF, S4-E4,S1-E4, S0-E4,S1-E1, S4-E1, S4-E0	Work program for fans. The program is activated after selecting PRO2 OFF: turning off the program S-supply; E-extract The number after the letter indicates the fan speed
------	-----	--	--

5.10.8 Menu #8 Application List

Name	Default setting	Range	Description
APP	4-WC	USER, 1÷11	Application select USER: Free application configuration DX: DX cooling system application
			1-11: Selecting among ready applications

5.10.9 Menu #9 AHU set: heat/cool

Name	Default setting	Range	Description
			Main heater:
			First heating section
HEAT1	0-10V	none, 0-10V, PWM, elec-1, elec- 2, elec-3	0-10V: 0-10V control PWM: PWM control of electric heater elec-1: ON/OFF control of electric heater – 1 stage elec-2: ON/OFF control of electric heater – 2 stage 19 elec-3: ON/OFF control of electric heater – 3 stage
		none, water,	Cooling coil:
COOL	DX-1	DX-1, DX-2,	DX-1: DX cooling ON/OFF one step
			DX-2: DX cooling ON/OFF two step
			Preliminary heater:
		none,	Mounted before the exchanger, it is used for pre-heating.
PHEAT	none	0-10V,	
		PWM	0-10V: 0-10V control
			PWM: PWM control of electric heater
HEAT2	none	none, 0-10V, PWM	Works as a second heating section connected in cascade to the main heater HEAT1. During dehumidification, if heaters HEAT1 and HEAT2 are defined then HEAT1 will be switch off and only HEAT2 will work. 0-10V: 0-10V control
			PWM: PWM control of electric heater
			Heat pump:
нымр	none	none HP-1 HP-7	HP-1: 0-10V for heating and cooling.
	none	110116, 117-1, 117-2	HP-2: 5-10V for heating
			5-0V for cooling













💮 asekol



Heat pump control

The HPUMP parameter is for AHU with heat pump control. After activating this parameter the outputs of the controller will be set as bellow:

	Heating/cooling	Heating/cooling	Electric heater	heating	Cooling &	operating mode select:
	control output	control output	control output	activation	heating	according to HPMD setting
	HPUMP=HP-1	HPUMP=HP-2			activation	(Menu #20)
	Y4	Y4	P2	U1-U2	Q6	Q7
Heating	0-10V	5-10V	PWM output	ON state	ON state	ON when HPMD=HEAT
mode						OFF when HPMD=COOL
Cooling	0-10V	5-0V	OFF state	OFF state	ON state	ON when HPMD=COOL
mode						OFF when HPMD=HEAT

Control for two-stage inverter units

To control a two-stage inverter unit with heating and cooling function, set the parameters as follows:

COOL=INV-2 : Two-stage inverter

HPUMP=HP-1 or HP-2 : Heat pump function

HPMD=HEAT or COOL : Selection of heating or cooling mode for output Q7

5.10.10 Menu #10 AHU set: recovery

Name	Default setting	Range	Description
ECON	bypass	none, bypass, inlet fan, 24VAC, contact	Exchanger control: bypass - 0-10V control for bypass and rotor actuator inlet fan - Exchanger without bypass with supply fan control for protection 24VAC - 24VAC on/off output for control contact - Potential free contact for on/off control
EPRO	В3		Exchanger protection: Protection by temperature sensor on the exchanger outlet.
DACO	none	No, Yes	Recirculation (Mixing chamber): OV - 0% recirculation and 100% fresh air 10V - 100% recirculation and 0% fresh air
GWC	none	No, Yes	Ground heat exchanger









PZH VentiAir s.r.o. Adolfovice 512 - Bělá pod Pradědem Czech Republic, IČ: 06935320

TEM

asek

ZE STARÉHO NOVÉ!

20



5.10.11 Menu #11 AHU set: temp control

Name	Default setting	Range	Description
			Temperature control:
TCON	cascade	cascade, supply	Cascade control with supply and
			room/exhaust sensor, or supply control.

5.10.12 Menu #12 AHU set: fan

Name	Default setting	Range	Description
		1 speed, 2 speed	Fan control:
FCON	freq	3 speed, 4 speed	1 speed – 4 speed: AC fan
		freq	freq: EC fan or inverter control

5.10.13 Menu #13 AHU set: CO₂, pressure

Name	Default setting	Range	Description
PID2	No	No, co2-fan, co2-damp, humidity, deshum, hum-desh	PID #2 control: CO2 or humidity controlco2-fanCO2 control by fanco2-dampCO2 control by dampershumidityHumidification controldeshumDeshumidification controlhum-deshHumidification /deshumidificationdeshumidification
PID3	No	No, pressure, CO2, humidity, deshum, hum-desh	PID #3 control: Pressure, CO2 or humidity controlpressurePressure control by fanCO2Additional CO2 controlhumidityHumidification controldeshumDeshumidification controlhum-deshHumidification / deshumidification
PID4	No	No, pressure, CO2, humidity, deshum, hum-desh	PID #4 control: Pressure, CO2 or humidity controlpressurePressure control by fanCO2Additional CO2 controlhumidityHumidification controldeshumDeshumidification controlhum-deshHumidification /deshumidification

5.10.14 Menu #14 AHU set: others

Name	Default setting	Range	Description
	No	No	Alarm output:
ALUUT	NO	Yes	Digital output for alarm signalling











21

PZH OTAL VentiAir s.r.o. Adolfovice 512 - Bělá pod Pradědem Czech Republic, IČ: 06935320



PR1IN	No	No Yes	Utility program-1: After enabling this function, the PRO1 program in Menu #7 will be controlled by the digital input indicated under this function.
-------	----	-----------	---

5.10.15 Menu #15 Supply temperature set

Name	Default setting	Range	Description
MIN	15 °C	0 ÷ 66 °C	Minimum temperature
MAX	35 °C	0 ÷ 70 °C	Maximum temperature

5.10.16 Menu #16 Cooling unit

Name	Default setting	Range	Description
AOFF	05 °C	0 ÷ 20 °C	Cooling unit off:
			External temperature that disables the cooling unit
ONTM	5 min	0 ÷ 5 min	Cooling unit run time
OFFTM	5 min	0 ÷ 5 min	Cooling unit standby time

5.10.17 Menu #17 DX unit

Name	Default setting	Range	Description
SETP	27 bar	0 ÷ 100 bar	Setpoint for the condenser
CSTAR	22 bar	0 ÷ 50 bar	Condenser fan start pressure
CUTOF	10 bar	0 ÷ 50 bar	Condenser fan stop pressure
VSTAR	5 sec	3 ÷ 20 sec	Electronic expansion valve start time
			before compressor
VSTOP	5 sec	3 ÷ 20 sec	Electronic expansion valve stop time
			before compressor
WLEAK	No	No, Yes	Water leak alarm action:
			No- Evaporator fan is not stopped on
			water leak alarm
			Yes- Evaporator fan is stopped on water
			leak alarm
TERMO	OFF	0 (OFF) ÷ 10°C	Energy saving mode:
			0 (OFF) – the compressor is constantly
			modulated to maintain the desired
			temperature
			A value > 0 - When the unit reaches
			temperature the compressor is switch off.
			It will
			start again when the temperature rises
			over the
			desired value by the value TERMO .

















5.10.18 Menu #18 Exchanger

Name	Default setting	Range	Description
	5°C	-10 ÷ +10°C	Exchanger protection:
ELIM			The temperature below which alarm is set
			and the defrost starts.
PRT	8.0 °C	0 ÷ 15 °C	Preheating temperature:
			The set value for preheating.

5.10.19 Menu #19 Recirc. damper.

Name	Default setting	Range	Description
DMODE	OFF	OFF, 10%,20%,100%, AUTO	Dampers control: OFF, 10100%: dampers manually set AUTO: dampers controlled by the algorithm
ODT1	-5 °C	-25 ÷ 30°C	Outdoor temperature low range value.
DACO1	20 %	0 ÷ 100 %	Outdoor temperature high range value.
ODT2	15 °C	-25 ÷ 30°C	Damper control low range value
DACO2	100 %	0 ÷ 100 %	Damper control high range value



5.10.20 Menu #20 Bypass and GHE

Name	Default setting	Range	Description
Bypass	AUTO	OFF, ON, AUTO	Bypass setting: OFF – Switch off Bypass ON – Switch on Bypass

PZH









..

aseko



			AUTO – Bypass is controlled depending on the outdoor and the outlet/indoor temperatures.
GWC	Αυτο	OFF, ON, AUTO	GHE setting: OFF – Switch off GHE ON – Switch on GHE AUTO – GHE is controlled depending on the temperature.

5.10.21 Menu #21 Heating set

Name	Default setting	Range	Description
			Preliminary heating:
PREH	ON	OFF, ON	Before the fans start the heater is warm
			up.
			Frost alarm clearing:
			MAN – Manual start of the unit after
FOVER	MAN	MAN, AUTO	clearing alarm manually.
			AUTO – Automatic alarm reset and unit
			start after the alarm signal disappears.
			Pump start temperature:
PUMP	0°C	-25 ÷ +15°C	Outdoor temperature below which the
			water heater pump will be activated.
			Heat pump operating mode select
			COOL: Q7 output closes for cooling mode
HPMD	COOL	COOL, HEAT	Q7 output opens for heating mode
			HEAT: Q7 output closes for heating mode
			Q7 output opens for heating mode



aseko

ZE STARÉHO NOVÉ!

SZÚ

5.10.22 Menu #22 Ventilating

Name	Default setting	Range	Description
CYCLE	0 h	0 ÷ 6 h	Ventilating cycle: Ventilating function is activated only









24

TEM VentiAir s.r.o. Adolfovice 512 - Bělá pod Pradědem Czech Republic, IČ: 06935320

••)



			when the unit is standby. The AHU is started every CYCLE period and stopped after VTIME time.
VTIME	0 min	0 ÷ 60 min	Ventilating time

5.10.23 Menu #23 PID set: Heating

Name	Default setting	Range	Description
PBAND	30.0°C	0 ÷ 999.9°C	PBAND
INT	100 sec	0 ÷ 6000 sec	Integral time
HYS	1.5°C	0.5 ÷ 10.0°C	Heating hysteresis
			Heating disabling:
HDIS	18°C	10÷22°C	Outdoor temperature above witch
			heating is disabled (SUMMER).

5.10.24 Menu #24 PID set: Cooling

Name	Default setting	Range	Description
PBAND	30.0°C	0 ÷ 999.9°C	PBAND
INT	100 sec	0 ÷ 6000 sec	Integral time
HYS	1.5°C	0.5 ÷ 10.0°C	Heating hysteresis
			Cooling disabling:
CDIS	15°C	10 ÷ 22°C	Outdoor temperature bellow witch
			cooling is disabled (WINTER).

5.10.25 Menu #25 Heat–Cool hyst.

Name	Default setting	Range	Description
HYS1	2.0°C	0.5 ÷ 9.9°C	Dead zone between heating and cooling.



5.10.26 Menu #26 PID set: CO₂^{Set temperature - HYS1}

Range Set temperaturescription Name Default setting PBAND 30 PBAND $1 \div 4000$ INT 100 sec 0 ÷ 6000 sec Integral time









PZH VentiAir s.r.o. Adolfovice 512 - Bělá pod Pradědem Czech Republic, IČ: 06935320

TEM

ase

ZE STARÉHO NOVÉ!

..



5.10.27 Menu #27 PID set: pressure

Name	Default setting	Range	Description
PBAND	500	1 ÷ 4000	PBAND
INT	10 sec	0 ÷ 6000 sec	Integral time

5.10.28 Menu #28 PID set: humidifying

Name	Default setting	Range	Description
PBAND	30	1 ÷ 4000	PBAND
INT	100 sec	0 ÷ 6000 sec	Integral time

5.10.29 Menu #29 Measure ranges

Name	Default setting	Range	Description
			Input range for X1 (PID2):
X1R	100	0 ÷ 100	Setting the measuring range for input X1 (input for PID2 control). This is the
			measurement value corresponding to 10V
			signal from the transmitter.
			Input range for X2 (PID3):
		0 ÷ 1000	Setting the measuring range for input X2
X2R	1000		(input for PID3 control). This is the
			measurement value corresponding to 10V
			signal from the transmitter.
	1000	0 ÷ 1000	Input range for X3 (PID4):
			Setting the measuring range for input X3
X3R			(input for PID4 control). This is the
			measurement value corresponding to 10V
			signal from the transmitter.
			Temperature shift:
050	0°C	0÷15.0°C	The value for shifting down the
UFS			temperature characteristic. The sensed
			value is decreased by the value OFS.

5.10.30 Menu #30 Units and flow

Name	Name	Default setting	Range
UNIT1	none	none, C, %RH, %, Pa, m3/h, ppm, m/sec, sec, min, h	Unit fo X1 input: The unit to display for the sensed value.
UNIT2	none	none, C, %RH, %,	Unit fo X2 input:













VentiAir s.r.o. Adolfovice 512 - Bělá pod Pradědem Czech Republic, IČ: 06935320



		Pa, m3/h, ppm, m/sec, sec, min, h	The unit to display for the sensed value.
UNIT3	none	none, C, %RH, %, Pa, m3/h, ppm, m/sec, sec, min, h	Unit fo X3 input: The unit to display for the sensed value.
К2	0		K coefficient of the fan (X2 input) The flow is calculated according to the formula: Flow = K x square_root(Pressure)
КЗ	0		K coefficient of the fan (X3 input) The flow is calculated according to the formula: Flow = K x square_root (Pressure)

5.10.31 Menu #31 Fan setting

Name	Name	Default setting	Range
			Exhaust/supply ratio:
FCOEF	1.00	0.5 ÷ 2	Exhaust fan speed ratio to supply fan.
			Exhaust = FCOEF x Supply.
			Fan minimum speed:
FMIN	10 %	10÷25	The speed below which the fan cannot go
			down during speed modulation.
			Fan modulation start:
			Defines when the supply fan starts
FMOD	7 °C	-25 ÷ 10 °C	modulating to protect the exchanger. This
			is the number of degree C above the
			exchanger protection value ELIM.
START	0 sec	0 ÷ 100 sec	Start delay
STOP	0 sec or 30 sec	0 ÷ 100 sec	Stop delay
PREST	60 sec	10 ÷ 300 sec	Fan pressure guard time

5.10.32 Menu #32 Gear setting

Name	Name	Default setting	Range
SPD1	25%	10 ÷ 100 %	Fan speed for gear 1
SPD2	50%	10 ÷ 100 %	Fan speed for gear 2
SPD3	75%	10 ÷ 100 %	Fan speed for gear 3
SPD4	100%	10 ÷ 100 %	Fan speed for gear 4

5.10.33 Menu #33 Clock

Name	Default setting	Range	Description
H:M		00.00 ÷ 23.59	Hour: Minute
WDAY		SUN ÷ SAT	Day of the week











VentiAir s.r.o. Adolfovice 512 - Bělá pod Pradědem Czech Republic, IČ: 06935320

💬 asekol



DAY	1÷31	Day of the month
MON	JAN ÷ DEC	Month
YEAR	20 ÷ 40	Year

5.10.34 Menu #34 Communication

Name	Default setting	Range	Description
			Slave address:
ADR	001	1 ÷ 255	Slave address for Modbus
			communication.
MODE	RTU	RTU, ASCII	MODBUS mode
	9600	2400, 4800,	Baud rate
KATE		9600, 19200	
DADIT	LACK	NONE, ODD.	Darity
PARII		EVEN	Pality
BITNR	8	7,8	Bit number
STBIT	1	1, 2	Stop bit number

5.10.35 Menu #35 Simulation

Name	Default setting	Range	Description	
CINA			Outputs control: Simulation mode allows to manually control the outputs. After power on the	
SIM	OFF	OFF, ON	simulation is always in the off state. OFF – Normal operation of the unit	
			ON – Manual control mode	

5.10.36 Menu #36 Password setting

Name	Default setting	Range	Description	
			User password: access level 1	
User			The lowest access level. User can edit	
	0	0 ÷ 999	desired values like set temperature, CO2,	
			schedule but cannot edit the	
			parameters of the application for AHU.	
	0	0 ÷ 999	Admin password 1: access level 2	
A alua in 1			All parameters can be edited except the	
Aummi			password for admin2 and the AHU	
			running time counter.	
			Admin password 2: access level 3	
Admin2	11	0 ÷ 999	The highest level. All parameters can be	
			edited.	









💮 aseko

ZE STARÉHO NOVÉ!





28



5.10.37 Menu #37 Language select

Name	Default setting	Range	Description
LANG	ENG	ENG, POL, CZ	Language

5.10.38 Menu #38 Information

5.10.39 Menu #39 Login

Name	Default setting	Range	Description	
LOGIN		0 ÷ 999	Login: Enter password for parameter editing. Parameters are visible without login, but some need login for editing.	





6 **E**THERNET

uManager 10 is a converter with built-in http server, which enables remote management of air handling units controlled by Uni Control System controllers by mean of a smartphone, tablet or computer. Communication with the is done via a website with a graphic interface, so you can manage the unit from anywhere in the world if the network is available. You can connect from iOS and Android or Windows devices. The smart interface recognizes the type of terminal and adapts automatically to it. The site works under various Internet browsers like Firefox, Chrome, Safari etc

6.1 SAMPLE INTERFACE PAGES:



6.2 CONNECTION

Connect the converter from one side to the controller through the RS485 serial port (terminals A, B) and on the other hand to the Internet socket.

A 24VAC supply must be connected to the G0, G terminals

Descriptions of symbols:

- G0, G: 24 VAC power supply
- A,B: RS485 serial port

6.3 LED DESCRIPTION

- **POWER**: Power supply signalling
- **Modbus**: Modbus communication signalling Lights up when the transmission starts on Modbus. Goes off at the end of broadcasting
- **100Mbps**: LED lights up when the physical layer negotiates 100 MBps transfer rate. Goes off when the cable is disconnected
- **ETH_Link**: The LED lights up when the application has received the packet and is lit for 200 ms
- **RESET**: Device reset
- FACT RESET: Restore factory settings







Models for AUTODESK REVIT

VentiAir s.r.o. Adolfovice 512 - Bělá pod Pradědem Czech Republic, IČ: 06935320



	DDD	
POWER	RESET	
0 100Mbps 0 ETH_Link	FACT RESET	

6.4 CONVERTER CONNECTION

Enter the IP address of the device, the default values are:

- IP: 192.168.0.50
- Address mask IP: 255.255.255.0
- TCP Port: 80
- Modbus: ASCII, 9600 baud, 8 bit data, 1 bit stop, No parity, address 1, delay 30

6.5 CONVERTER SETTINGS

After entering the converter's IP address, the login screen should appear in the browser. Enter your login and password there and click "Login". The default account is:

- Login: admin
- Password: admin

After logging in, select the option **Detail** at the bottom right of the screen.

In the subpage **Ethernet** Configuration, you must replace the factory IP with your own and set the network settings.

In the subpage **Modbus** Configuration, the communication parameters of the converter with the UCS controller must be set. The communication parameters must be identical to those set on the UCS controller.

For the ERC20 and CU24V1 controllers, you can find the communication parameters in the RMC20 panel menu.

For UCS controllers, the parameters can be found in the controller menu.

After entering new data, the converter is reset automatically and you must enter the new IP into the

browser to connect to the converter.











7 CU24V2 CONTROLLER – MODBUS REGISTER LIST

7.1 REGISTER LIST WITH ADDRESS (FUNCTION 03, 06)

Protocol: MODBUS RTU, MODBUS ASCII

Warning:

MODBUS address is the address that is specified directly in the MODBUS protocol frame,

Registers in the controller have double Modbus address. The second address is for use in the range

from 0 to 9999 because not all software are able to use address above 9999. To have access to the

second address just subtract the value **55536** from the address listed in the tables.

Items in red colour are not available.

Register Name	Register	MODBUS Address
Login registers	 Login register	64777 64778
PWM outputs P NOTE: 1. Control values are in % with 1/10 precision. After reading the register value the dot should be placed artificially Ex.: Reading the value 257 should be treated as 25.7% 2. The value 0x8000 means, the parameter is not available.	0 – P1 1 - P2 n - Pn	65472 65473 65472+n
0-10V analog outputs NOTE: 1. Control values are in % with 1/10 precision. After reading the register value the dot should be placed artificially Ex.: Reading the value 257 should be treated as 25.7% 2. The value 0x8000 means, the parameter is not available.	0 – Y1 1 – Y2 n – Yn	65408 65409
Alarms register bit alignment Read and write Alarms register are 32-bit wide (see the description of registers)	0 – 1 – R1H: current alarm - High register 2 – R1L: current alarm – Low register	65280 65281 65282







Models for AUTODESK REVIT*

VentiAir s.r.o. Adolfovice 512 - Bělá pod Pradědem Czech Republic, IČ: 06935320

ZE STARÉHO



Desired values: read/write	 0 - Desired temperature for the main heating/cooling . 2 - Desired value for CO₂ control	65216 65218 65219 65220 65221 65222 65223 65223
Device operating state	0 – Register 1 1 – Register 2	65152 65153
Sensed values 1. The sensed values have 1/10 precision. After reading the sensed value it should be divided by 10. Ex: Reading the number 257 should be treated as 25.7 2. Reading the value 0xFFFF means that , the parameter does not exist	 0 - Indoor/exhaust temperature	64896 64897 64899 64902 64904 64906 64908 64921
Reading control values Comments: 1. The control values are in % with 1/10 precision. After reading the sensed value it should be divided by 10. Np.: Reading the number 257 should be treated as 25.7%	0 – Main heater control: 0-100% 1 – Secondary heater control: 0-100% 2 – Cooling control: 0-100% 3 – PID 2 control – humidifying: 0-100% 4 – PID 2 control – CO_2 / dehumidifying: 0-100% 5 – PID 3 control – pressure/humidifying: 0-100% 6 – PID 3 control – CO_2 / dehumidifying: 0-100% 7 – PID 4 control - pressure/humidifying: 0-100%	64832 64833 64834 64835 64836 64837 64838 64839
2. The value 0x8000 means that the given the parameter is not configured (does not exist)	8 – PID 4 control - CO ₂ / dehumidifying: 0-100% 9 – Exchanger control: 0-100% 12 – Supply fan control 13 – Extract fan control	64840 64841 64844 64845









AND OUR ALL DE LO VentiAir s.r.o. Adolfovice 512 - Bělá pod Pradědem Czech Republic, IČ: 06935320

💮 asekol

ZE STARÉHO NOVÉ!

STÁTNÍ ZDRAVOTNÍ ÚSTAV

SZÚ



Start/Stop command and system operating state	Start/Stop command Write: Start=0x00AA, Stop=0x0055 Read: System operating state 0 – system stopped by the operator 1 – system stopped by the ECO mode function 2 – system stopped by schedule 3 – 4 – 5 – System running	64640
Parameters – group 1	 MIN: Supply minimum temperature	63233 63234 63288 63289 63291
Parameters – group 2	19- Temperature control type 0 – Cascade control 1 – Supply control	63187

7.2 OPERATING STATE REGISTER DESCRIPTION

Register 1

Bit nr	Process	Availability
0		No
1		No
2		No
3		No
4		No
5		No
6	Delay at start of the unit	
7	Delay at stop of the unit	
	Device state:	
	0 - system stopped by the operator	
	1 - system stopped by the ECO mode function	
8 - 10	2 - system stopped by schedule	
	3 -	
	4 -	
	5 - System running	
11	Valve setting before starting control	No
12	Pump testing	No
10	Temperature control of the preliminary heater – heating	
12	process	
11	Temperature control of the preliminary heater – cooling	No
14	process	NU







SZÚ



A PZH ON DUKT Z ATESTEM VentiAir s.r.o. Adolfovice 512 - Bělá pod Pradědem Czech Republic, IČ: 06935320

💮 asekol



Register 2

Bit nr	Process	Availability
0	Primary heating (main heating) – Indoor temperature control	
1	Secondary heating	No
2	Cooling – Indoor temperature control	
3	Exchanger exhaust air temperature control - heating	
4		No
5	Humidification process	No
6	Dehumidification process	No
7	Exchanger	
8	By-pass	No
9	GHE (Ground Heating Exchanger)	No
10	Inlet fan	
11	Extract fan	
12	FREE COOLING	No
13	Preliminary heating	
14	Fast heatibg	No
15	Fast cooling	No

0 - disabled; 1 - enabled

7.3 ALARM REGISTER DESCRIPTION R1H, R1L

RH - Register 1 (Most significant/high register)

Bit nr.	Alarm	Symbol	Availability
0		RH+	No
1		RH-	No
2		A19	No
3	Sensor break alarm	A20	
4	-		
5	Compressor low pressure	A22	
6	Compressor high pressure	A23	
715			

RL - Register 2 (Least significant/low register)

Bit nr.	Alarm	Symbol	Availability
0	Water heating coil frost alarm	A1	
1	Engine alarm (thermic)	A2	No
2	Inlet fan pressure guard alarm	A3	







aseko

ZE STARÉHO NOVÉ!

...

PZH

TEM



35



3	Extract fan pressure guard alarm	A4	No
4	Fire alarm	A5	No
5	High temperature alarm	A6	
6	Exchanger freezing alarm	A7	
7	Anti-freeze alarm	A8	No
8	Pump failure	A9	No
9	Filter pressure guard alarm	A10	
10	R1+	No	
11	R1-	No	
12	R2+	No	
13	R2-	No	
14	R3+	No	
15	R3-	No	

7.4 INPUT REGISTERS: FUNCTION 04

Inputs	Register address			
B1 – Exhaust sensor	0			
B2 – Supply sensor	1			
B3 – Exchanger sensor	2			
B4 – Outdoor sensor	3			
B5	4			
X1	256			
X2	257			
X3	258			

7.5 COILS (DIGITAL OUTPUTS): FUNCTION 01

Outputs	Q1	Q2	U1-U2	Q4	Q5	Q6	Q7	Q8
Function	Dampers	Bypass	Heating coil pump	Supply fan inverter start	Exhaust fan inverter start	Cooling unit 1-level	Cooling unit 2-level	Electric heater supply
Register Address	0	1	2	3	4	5	6	7

7.6 DISCRET INPUTS (DIGITAL INPUTS): FUNCTION 02

Inputs	E1	E2	E3	E4	E5	E6	E7	E8
Function	High temperature thermostat	Frost thermostat	Fan alarm	User function	Filter guard	Cooling unit alarm	System start	Fire alarm
Register Address	0	1	2	3	4	5	6	7













VentiAir s.r.o. Adolfovice 512 - Bělá pod Pradědem Czech Republic, IČ: 06935320

PZH