


# Operation instructions

Installation of roofs for outdoor assembly units



 **VentiAir**

Contact:

VentiAir s.r.o.  
Adolfovice 512  
790 01 Bělá pod Pradědem  
CZ – Czech Republic  
IČ: 06935320 DIČ: CZ06935320  
Email: obchod@ventiair.com; technical@ventiair.com  
Phone.: +420 602 500 287

The device has been manufactured in accordance with the EU standards EN1886, EN13053.

**This documentation must always be handed over to the user!**

**In case of non-compliance with the warranty conditions listed below in the documentation, VentiAir s.r.o. reserves the right to refuse warranty.**

Version 01/2021





Regular  
Production  
Surveillance  
Safety




www.tuv.com  
ID: 000073965



## 1 DESCRIPTION OF THE ROOF ASSEMBLY





Regular  
Production  
Surveillance  
Safety



www.tuv.com  
ID: 000073965

